


Apply to Floor




1. PREPARE FLOOR

Clean and dry the floor so SFS Grippy Mat will properly adhere.



2. STICKY SIDE DOWN


Remove pre-cut mat from the roll, then position the adhesive side toward the floor.



3. SMOOTH OUT

Smooth out mat with hands or a flat edge, pushing out air bubbles, and press into place.


Care & Maintenance



WEAR AND TEAR

If the adhesive on mat edges or corners lift, use a utility knife to remove the weakened piece of mat.

Cleaning



EVERY DAY CLEANING

Leave mat in place while you sweep, mop, scrub or vacuum according to your protocols. Daily cleaning will not affect custom-printed mats.



DEEP CLEANING


Deep clean and remove stains with a wet vac, extractor or Rug Doctor® — this will not affect custom-printed mats.



DEEP CLEANING

Excessive water, rain, snow or slush should be removed using a wet-vac, Rug Doctor® or extractor for best performance.

Removal



REMOVAL & CHANGEOUTS

Replace mat when it shows obvious signs of wear or a weakened bond to the floor. Peel up a corner and pull in a smooth motion.